

HDS PRO TOOL - MOUNTING

Mounting HDS - Hidden decking system

ESSVE
GET IT DONE



1. Adjust the tool according to the width of the board by pulling the grey button on the top of the tool.



2. Place the tool over the joist and clamp the tool to the board.



3. Place a screw in each installation hole. Use the spacers for the correct distance between the boards.



4. Screw the ESSVE HDS screw using the HDS bit with red marking. Always start with the outermost screw.



5. When joining boards: Install an additional joist at the joint.

*When using hardwood,
see www.essve.com.*